Floating Light Show Instructions

ON/OFF BUTTON

LID

BASE

1. Unscrew the lid from the base to reveal battery compartment on the underside of the lid.
2. Insert 3 x AAA batteries (not included) as indicated, matching the + & - symbols.
3. Replace the lid ensuring it is a tight fit.
4. Press the ON/OFF button to start. Press the ON/OFF button again to change light show effect.
5. To turn off, press and hold the ON/OFF button for 3 seconds.

Remove batteries when not in use